

**ORNL
MASTER COPY**

OAK RIDGE NATIONAL LABORATORY

operated by

UNION CARBIDE CORPORATION

for the

U. S. ATOMIC ENERGY COMMISSION



ORNL - TM - 266

Scf

930

EXPERIMENT FACILITIES OF THE OAK RIDGE GRAPHITE REACTOR

S. D. Sheppard

NOTICE


This document contains information of a preliminary nature and was prepared primarily for internal use at the Oak Ridge National Laboratory. It is subject to revision or correction and therefore does not represent a final report. The information is not to be abstracted, reprinted or otherwise given public dissemination without the approval of the ORNL patent branch, Legal and Information Control Department.

LEGAL NOTICE

This report was prepared as an account of Government sponsored work. Neither the United States, nor the Commission, nor any person acting on behalf of the Commission:

- A. Makes any warranty or representation, expressed or implied, with respect to the accuracy, completeness, or usefulness of the information contained in this report, or that the use of any information, apparatus, method, or process disclosed in this report may not infringe privately owned rights; or
- B. Assumes any liabilities with respect to the use of, or for damages resulting from the use of any information, apparatus, method, or process disclosed in this report.

As used in the above, "person acting on behalf of the Commission" includes any employee or contractor of the Commission, or employee of such contractor, to the extent that such employee or contractor of the Commission, or employee of such contractor prepares, disseminates, or provides access to, any information pursuant to his employment or contract with the Commission, or his employment with such contractor.



EXPERIMENT FACILITIES
OF THE
OAK RIDGE GRAPHITE REACTOR
OAK RIDGE NATIONAL LABORATORY
OAK RIDGE, TENNESSEE



ORNL-TM-266

EXPERIMENT FACILITIES OF THE OAK RIDGE GRAPHITE REACTOR

S. D. Sheppard

DATE ISSUED

AUG 17 1962

OAK RIDGE NATIONAL LABORATORY
Oak Ridge, Tennessee
Operated by
UNION CARBIDE CORPORATION
for the
U. S. ATOMIC ENERGY COMMISSION



Table of Contents

	Page
Introduction	1
Table 1. Research Openings into Graphite Reactor	2
Section 1. The Graphite Matrix	3
Figure 1.1. Details of Graphite Matrix	4
Figure 1.2. Details of Graphite Block Dimensions	5
Section 2. Charging Holes	6
Figure 2.1. Vertical Section Through Reactor	7
Figure 2.2. OGR Fuel Loading Pattern	8
Figure 2.3. Charging Hole Assembly	9
Figure 2.5. Charging Hole Plug	10
Section 3. Core Holes	11
Figure 3.1. Core Hole Dimensions	12
Section 4. Experiment Holes	13
Figure 4.1. North Face of Reactor	14
Figure 4.2. South Face of Reactor	15
Figure 4.3. Four-Inch Square Holes and Liners	16
Figure 4.4. Plan View of Reactor Top	18
Figure 4.5. Exposure Chamber of East Animal Tunnel	19
Figure 4.6. Exposure Chamber of West Animal Tunnel	20
Figure 4.7. Thermal Column Hole	21
Figure 4.8. Inclined Biological Tunnel	22
Figure 4.9. Elevation of Discharge End Wall	23
Figure 4.10. West Face of Reactor	24
Figure 4.11. Holes 40 - 45	25
Figure 4.12. Plug for Holes 40 - 47	26
Figure 4.13. Top View of Reactor	28
Figure 4.14. Holes 46 and 47	29
Figure 4.15. Holes 30 - 37	30
Section 5. Control and Maintenance	31
Figure 5.1. Holes 7, 8, 9, and 10	32
Figure 5.2. Gravity Operated Safety Rods	33
Figure 5.3. Holes 11 and 12	34
Figure 5.4. Elevation of North and South Faces	35
Figure 5.5. Scanner Hole and Plug	37



Introduction


This publication contains up-to-date descriptive material and dimensional sketches of the ORNL Graphite Reactor and its experiment facilities. Information of this type should be useful to experimenters in selecting appropriate facilities in designing equipment and in understanding the relationship of their experiments to others in the reactor and to the parts of the reactor itself.

Table 1. Research Openings into Graphite Reactor

Kind of Facility	Number of Facilities	Maximum Thermal Neutron Flux	In-Cd Ratio	Gamma (R/hr)	Approximate Temperature
4-in.-sq horizontal	42	3.6×10^{11} to 1×10^{12}	20	3×10^5 to 8×10^5	35°C to 160°C
4-in.-sq vertical	3	8×10^{11}	20	6.7×10^5	135°C to 140°C
4-in.-dia.	1	8.9×10^{11}			50°C
1.38-in.-diameter horizontal	4	1×10^{12}	20	9×10^5	35°C
2 3/4 in. x 3/8-in. foil slot	1	1.1×10^{12}	20	9×10^5	160°C
Unused fuel channels in core region	5	5.5×10^{11} to 1×10^{12}	20	4.5×10^5 to 9×10^5	35°C
Unused fuel channels in reflector region	418	10^{10} to 3×10^{11}		10^4 to 3×10^5	30°C to 50°C
14-in.-sq biological tunnel lead-lined	1	1.3×10^9	~70 Cd Ratio (Mn)	200	25°C to 35°C
14-in.-sq biological tunnel, bare	1	5×10^8	73 Cd Ratio (Mn)	3.4×10^3	25°C to 35°C
7-in. x 3-in. x 3-in. inclined biological tunnel	1	1×10^9	10^5	360	Room Temperature
5-ft-sq vertical thermal column	1	1.5×10^7	~ 10^6	135 at top of column	Room Temperature
2 1/2-ft-sq horizontal thermal column	1	5×10^9	130	1.2×10^4	Room Temperature
Unused 9-in.-sq ionization chamber holes	2	10^7 to 10^9	~70 Cd Ratio (Mn)	~ 5×10^3	35°C

1. The Graphite Matrix


The graphite is built up as a 24-ft-square section 24-ft - 4-in. high, Figure 1.1. There are 73 courses of 4-in.-square graphite blocks of dimensions from 8-in. to 50-in., Figure 1.2. A one-inch space was left on the north and south sides, between the graphite and concrete, and was packed with asbestos rope for thermal insulation.



- LEGEND**
- 1. FUEL CHANNELS
 - 2. CONTROL ROD OPENING
 - 3. EXPERIMENTAL OPENING
 - 4. GRAVITY SAFETY ROD OPENING
 - 5. GRAPHITE SPLINE

CONCRETE FOUNDATION

Fig.1.1 DETAILS OF GRAPHITE MATRIX ASSEMBLY



2. Charging Holes

The metal channels through the blocks, Figures 1.1 and 2.1, are arranged on 8-inch centers at the face of the reactor in 36 horizontal rows of 35 holes each, Figure 2.2. The openings are 1 3/4-in. square in cross section set on edge and are made by two 45° cuts in the sides of two adjacent blocks. The ends of the cuts are chamfered 1/8-in. x 3/8-in. to a 30° angle so as to prevent any shoulder that might cause blocking of the metal as it is pushed through the channels in case the graphite should shift slightly during operation of the reactor. The charging tubes, Figure 2.3, extend two inches into the channels at the front face. The stepped plugs for the charging tubes are shown in Figure 2.4. At the back ends of the channels, the graphite is cut back in a rectangular opening 2 1/2-in. x 3 1/2-in. long to prevent any possible hanging up of metal slugs at the top of the channel when they are discharged.




FIG. 2.1 VERTICAL SECTION THROUGH REACTOR





FIG. 2.2 OGR FUEL LOADING PATTERN



NOTE:
 Entire plug galvanized after
 assembly .0035" to .004"
 thick. Interior filled with 1/8"
 lead shot and paraffin.



Fig.2.4 CHARGING HOLE PLUG

3. Core Holes

Holes through the shield are located on both the front and rear faces, Figures 2.1 and 3.1. Charging tubes through the front face plug, with the exception of the one for the foil slot, are the same as those for the rest of the reactor. The charging hole for the foil slot is rectangular in cross section and is closed by a four-step solid steel plug.

The plug in the back face contains a 2-S aluminum tank which can be filled with water to act as a radiation shutter. A concrete-shielded water tank just outside the hole normally acts as the biological shield when the shutter tank is empty. Shielding configurations are built up in the outer tank and checked for attenuation efficiency.

A-53781



- DIM. "A" 2'-9 ¹/₂" x 3'-1 ¹/₂"
- DIM. "B" 2'-4 ⁹/₃₂" x 2'-8 ³/₁₆"
- DIM. "C" 2'-2 ²⁵/₃₂" x 2'-6 ⁵/₈"
- DIM. "D" 2'-1 ⁵/₁₆" x 2'-5 ⁷/₆₄"
- DIM. "E" 1'-11 ¹⁹/₃₂" x 2'-3 ⁴¹/₆₄"

4. Experiment Holes

4.1. Four-Inch-Square Holes

Most experiments are placed in the four-inch-square holes in the north and south faces of the reactor, Figures 4.1 - 4.3. The hole openings are closed with 4-in. by 4-in. by 6-ft long graphite stringers with holes drilled in them to accommodate experiments, instruments, etc., as needed. The outer one-ft section is plugged with a 4 5/8-in. by 4 5/8-in. by 1-ft laminated steel and masonite shield. If an experiment is such that this internal shielding cannot be used, additional outside protection is necessary.

4.2. "Stringer" Hole

Hole 14 is used specifically for the irradiation of either experiment or radioisotope targets. It is opened for inspection or removal of specimens only during the weekly reactor shutdowns.

4.3. Pneumatic Tubes

Hole 22 contains both a large and a small pneumatic-tube facility. The large tube will accommodate "rabbits" (special capsules in which specimens are placed) 1.280-in. in diameter and 3.516-in. long; the small tube accommodates "rabbits" 0.75-in. in diameter and 2.5-in. long. The large tube will transport specimens weighing up to 59 grams net.

These tubes make it possible to irradiate both experiment and radioisotope specimens for short periods without requiring a reactor shutdown for insertion and removal.

4.4. Hole 71

Hole 71, Figure 4.13 is a 4-in.-diameter vertical hole that has been fitted with a 3-in. liner so that it may be cooled by air circulation. Specimens are placed in an aluminum container and are lowered to the desired level; or, in special cases, they are suspended at the desired level with waxed linen string. Entrance to the hole is through a six-place rotating shielded magazine. Irradiated samples may be stored in the magazine until they decay enough to be handled safely. The facility







FIG. 4.3 ASSEMBLY OF 4"-SQ. HALF-HOLE

allows short-term irradiations at near room temperature at a maximum neutron flux density of 8.9×10^{11} n/cm²/sec.

4.5. Biological Tunnels

Two biological tunnels are located in the top shielding on the south side of the reactor, Figure 4.4. Figure 4.5 shows the irradiation chamber of the tunnel to the east and the third of three gates through which the specimen container must pass in order to reach the chamber. The west tunnel is identical in size but is lined with 4-in. of lead as shown in Figure 4.6.

The gates operate vertically in channels open to the top of the reactor shield. Shielding of the gate channels is accomplished by the use of stepped concrete plugs with small holes to accommodate the lifting cables.

4.6. Thermal Column and Inclined Biological Tunnel

The thermal column, Figure 4.7, is a stack of graphite blocks in a 5-ft square hole through the roof of the reactor shield and centered over the reactor core. The top is shielded by a 5-ft square aluminum tank of water with lead and cadmium shielding around the sides. Materials to be irradiated or radiation shield configurations to be tested are lowered through the water to the bottom of the tank.

The inclined biological tunnel, Figure 4.8, is built into the thermal column. The irradiation chamber is encased in a 4-in. thick layer of bismuth metal and is covered with a 4-in. bismuth plug backed by a 4-ft graphite plug in the insertion hole. Specimens, maximum size 7-in. x 3-in. x 3-in., are placed in a graphite box affixed to the lower end of the bismuth plug and are lowered into the irradiation chamber by means of a motor-driven hoist.

4.7. Periscope or Utility Holes

Holes 40 - 45, Figures 4.9, 4.10, and 4.11, are 6-in. holes that were designed for either general utility or to accommodate periscopes for observation of the discharge face of the reactor matrix. When not in use, the holes are closed with stepped shield plugs, Figure 4.12. At present, Hole 40 contains an ionization chamber used in reactor control.




FIG. 4.4 PLAN VIEW OF REACTOR




FIG. 4.6 EXPOSURE CHAMBER OF WEST BIOLOGICAL TUNNEL

A-53788





FIG. 4.7 THERMAL COLUMN HOLE

UNCLASSIFIED
ORNL-LR-DWG. 6421



A-53789




FIG. 4.9 ELEVATION OF DISCHARGE END WALL




FIG. 4.10 WEST FACE OF REACTOR




FIG. 4.12 PLUG FOR HOLES 41-47

Holes 46 and 47 through the top shield, Figures 4.13 and 4.14, are similar in construction to Holes 40 - 45 and were designed to allow periscopic observation of the exit-air manifold from the reactor top.

4.8. Nine-Inch Holes

Holes 30 - 37, Figures 4.1, 4.2, and 4.15, are 9-in. square holes designed for either ionization chambers or for large experiments. At present, Holes 32, 33, and 36 contain uncompensated ionization chambers which initiate signals for three independent safety channels. Compensated ionization chambers in Holes 34 and 37 initiate signals that are used for a micro micro ammeter and a power-level recorder, respectively. Holes 31 and 35 have been permanently closed. A steel "H" beam extends from Hole 31 to Hole 35 across the top of the graphite.




FIG. 4.13 TOP VIEW OF REACTOR

A-53794






FIG. 4.14 HOLES 46 AND 47

* PART OF LEAD HAS BEEN REMOVED FROM THESE HOLES



TOP VIEW - HOLES 30* AND 34



SIDE VIEW - HOLES 30* AND 34




FIG. 4.15 SIDE VIEW - HOLES 32, 33, 36 AND 37

5. Control and Maintenance

The following holes were not designed as experimental facilities. However, modifications of the safety and control systems have released some of them to be converted to experiment facilities.

5.1. Safety Rods

Holes 7, 8, 9, and 10, Figures 4.13, 5.1, and 5.2, were designed to let safety rods No. 7, 8, 9, and 10 drop into the reactor through the top shielding. Holes 7, 8, and 9 were modified to accommodate new safety rods, 3 1/2-in. square by 9-ft long, containing 1/16-in. thick cadmium sheet in their walls. The increased reactivity worth of these rods made it possible to remove No. 10 from the reactor and Hole 10 was converted to an experiment facility.

Holes 11 and 12, Figure 5.3, were also changed from safety holes to experiment facilities when it was found that they were not needed for their original purpose, boron-steel shot tubes.

5.2. Shim Rods and Regulating Rods

Both shim rods and regulating rods enter the reactor from the north side. Shim rods No. 3, 4, 5, and 6 operated in Holes 3, 4, 5, and 6, Figure 5.4. Rods No. 3 and 4 were found to be unnecessary for reactor control, so they were removed and the corresponding holes were converted to experiment facilities.

Rods No. 1 and 2, the regulating rods, are used for operating the reactor while in the "manual" mode because their drives are designed to insert or withdraw small increments of reactivity for smooth control in this mode.

In the "automatic" mode, shim rod No. 6 is fully withdrawn and is used as a safety rod. No. 5 shim rod is operated by the servo-control system and becomes the regulating rod. Regulating rods 1 and 2 become shim rods and are inserted or withdrawn only to keep the No. 5 rod operating in a limited reactivity range.






FIG. 5.1 HOLES 7, 8, 9, AND 10



PARTIAL PLAN OF REACTOR



SECTION "A-A"

FIG. 5.2 GRAVITY SAFETY RODS




FIG. 5.3 HOLES 11 AND 12

5.3. Scanner Holes

These thirty-five 4-in. diameter holes extend through the top shield above the exit-air manifold. They are located on 8-in. centers above the fuel channels and are used as observation and maintenance ports. When the reactor is operating, the scanner holes are closed with the stepped shield plugs shown in Figure 5.5.

A-53800





FIG. 5.5



Distribution

1. F. T. Binford
2. C. D. Cagle
3. W. R. Casto
- 4 - 204. J. A. Cox
205. C. B. Gaither
206. H. V. Klaus
207. L. E. Stanford
208. W. H. Tabor
- 209 - 223. DTIE
224. Research and Development Division, ORO
- 225 - 226. Central Research Library
227. Document Reference Library
- 228 - 229. Laboratory Records
230. ORNL-RC

