

Nuclide Inventories with ORIGAMI for Criticality Safety Models

Rabab Elzohery

2023 SCALE Users' Group Workshop April 26–28, 2023 Oak Ridge National Laboratory



ORNL is managed by UT-Battelle LLC for the US Department of Energy



Practical application of ORIGAMI to generate nuclide inventory data for use in criticality safety models

- Goal: determine bias and bias uncertainty for burnup credit criticality safety that are associated with isotopic depletion validation.
- The nuclide compositions uncertainty is propagated to bias and uncertainty in k_{eff} of reference models.
- Cask criticality models served as reference models under NUREG-7108¹ (2012) and NUREG-7109² (2012).
- Each reference model has unique assembly-average burnup and enrichment.
- The cask consists of 32 W 17x17 fuel assemblies. Each fuel element is discretized into 18 axial zones with different burnups.
- Using TRITON to compute the nuclides inventory is computationally expensive.
- TRITON is used to generate burnup-dependent ORIGEN libraries for the fuel assembly and then ORIGAMI uses these libraries to rapidly generate nuclides inventory for any enrichment/burnup combination.
- This approach is more efficient since TRITON depletion calculation takes **hours** whereas ORIGAMI takes **seconds**.

^[2] J. M. Scaglione, D. E. Mueller, J. C. Wagner, W. J. Marshall, "An Approach for Validating Actinide and Fission Product Burnup Credit Criticality Safety Analyses—Criticality (k_{eff}) Predictions ", NUREG/CR-7109, U.S. Nuclear Regulatory Commission, Office of Nuclear Regulatory Research (2012).



^[1] G. Radulescu, I. Gauld, G. Ilas, and J. Wagner, "An Approach for Validating Actinide and Fission Product Burnup Credit Criticality Safety Analyses–isotopic Composition Predictions," NUREG/CR-7108, U.S. Nuclear Regulatory Commission, Office of Nuclear Regulatory Research (2012).

Overview of the workflow

- Generate ORIGEN reactor libraries at different assembly enrichments.
- Each library includes cross sections at different burnups
- Rapidly calculate inventory at different burnups/enrichments
- Use the resulting nuclide inventory in CSAS model to calculate k_{eff}







ORIGAMI



CSAS



```
=origami
   title='PWR cask'
   options{ft71=all, stdcomp=yes,fdens=10.5216}
   libs=[ "w17x17_waba" ]
   fuelcomp{
        mix(1) { stdcomp(fuel) {
            base=uo2 iso[92235=6.0 92238=94.0]
        }
    }
   hist[
        cycle{ power=60 burn=500 nlib=15}
        cycle{ down=100 }
        cycle{ down=100 }
        cycle{ down=100 }
    ]
   end
```



CSAS cask model


TRITON assembly model




ORIGAMI tips 1/3

- fdens must be specified if actual fuel density is different from the default density value in ORIGAMI (10.4 g/cm³)
- Using wrong fuel density will result in an inaccurate isotopic composition and accordingly wrong \mathbf{k}_{eff}

```
=origami
  title='PWR cask'
  options{ft71=all, stdcomp=yes, fdens=10.5216}
```





OAK RIDGE
National Laboratory

default fdens

ORIGAMI tips 2/3

nlibs: not too many, not too few

- nlibs: number of ORIGEN library burnup-interpolations during the cycle.
- Few interpolation points might cause inaccurate results because of the error introduced by interpolation.
- Too many interpolation points could add unnecessary computational cost.
- Burnup step is recommended to be ~ 2 GWd/MTU.

```
hist[
   cycle{ power=60 burn=500 nlib=15}
   cycle{ down=100 }
   cycle{ down=100 }
]
end
```

ORIGAMI tips 3/3

Format of output nuclides inventory in atom/barn-cm to be provided to CSAS

Option 1: Use stdcomp=yes

- generates separate text file myInput_compBlock.txt
- concentrations are given at the last time step
- the resulting file can be used directly in CSAS input.

```
=origami
  title='PWR cask'
  options{ft71=all, stdcomp=yes, fdens=10.5216}
```

o-16	1001	0	4.6818E-02	293.0	end
u-234	1001	0	1.0369E-08	293.0	end
u-235	1001	0	3.8858E-04	293.0	end
u-236	1001	0	2.1565E-05	293.0	end
u-238	1001	0	2.2841E-02	293.0	end
np-237	1001	0	9.6119E-07	293.0	end
pu-238	1001	0	5.3095E-08	293.0	end

Option 2: Use OPUS


- generates separate text file myInput.plt
- concentrations are given with lower precision

```
=opus
data="myInp.f71"
title="cask"
typarams=nuclides
nrank=22
symnuc=U234 U235 U236 U238 Np237 Pu238 Pu239 Pu240 Pu241
Tc99 Ru101 Rh103 Ag109 Cs133 Nd143 Nd145 Sm147 Sm149 Sm150
Sm151 Eu151 Sm152 Eu153 Gd155 o16 end
sort=no
units=ATOM
end
```



Verify consistency of ORIGAMI-based methodology for generating axial fuel composition to an old methodology

new – based on ORIGAMI with ORIGEN reactor libraries generated with SCALE 6.1.3/238 gr ENDF/B-VII.0 old – based on STARBUCS with ORIGEN reactor libraries generated with SCALE 6.1.3/238 gr ENDF/B-VII.0



Burnup=40 GWd/MTU, Enrichment=4.63506 %

